

Tools required:

• Socket wrench or ring spanner

Parts supplied:

- 1 x Aperta Wind deflector
- 2 x Black brackets
- 2 x Plastic rotary knobs
- 2 x Plastic washers















