



## PREMIUM AFTERMARKET ROADSTER BARS & WIND DEFLECTORS

### TOYOTA MR2 ROADSTER BARS AND WIND DEFLECTOR



Expert Fitment Required  
Montage durch Fachwerkstatt erforderlich  
Montaje sólo por el concesionario  
Montage par spécialiste nécessaire  
E' necessario in officina specializzata  
Especialista em montagem requerido  
Montage door vakman nodig  
Montage ved professionelt værksted påkrævet  
Nødvendig med montering fra fagvevkersted  
Verkstadsmontage erfordras  
Asennus tarpeen merkkikorjaamossa  
Montáž ve specializované dílně nutná  
A szereléshez szakműhely kell  
Konieczny montaż przez warsztat specjalistyczny  
Να τοποθεη από συνεργείο

#### What's in the box:



Chrom Bars Part No: WTP00B06



Wind Deflector Part No: 36.23.01.01



Black Bars Part No: WTP00B19



## PREMIUM AFTERMARKET ROADSTER BARS & WIND DEFLECTORS

### STEP 1

Open the top and fold both seats forward.



### STEP 2

Remove the bottom cover using an upholstery removal tool to avoid scratches.



### STEP 3

Push down the center of the plastic plugs which hold the covers left and right of the luggage compartment.





## PREMIUM AFTERMARKET ROADSTER BARS & WIND DEFLECTORS

### STEP 4

Remove both plugs using an upholstery removal tool.




### STEP 5

Open the luggage compartment and pull the cover forward.



### STEP 6

Remove these 2 bolts with a 13mm socket.





## PREMIUM AFTERMARKET ROADSTER BARS & WIND DEFLECTORS

### STEP 7

Remove the plastic cover which hold the bolts of the factory fitted wind deflector.



### STEP 8

Remove the factory fitted wind deflector using a 10mm socket.



### STEP 9

There is a right and a left roll bar. Please make sure you have the correct roll bar for each side. The bottom bracket of the roll bar can be adjusted (this might have shifted during transport). You can loosen the bolt on the bottom and turn the bracket. Please make sure the bracket is in the correct position.





## PREMIUM AFTERMARKET ROADSTER BARS & WIND DEFLECTORS

### STEP 10

Slide the side bracket of the roll bar over the bolt at side of the car. Line up the middle brackets to the bolts of the plexiglass wind deflector located in the vehicle. Push the brackets over the bolts, some force might be needed. If your plastic cover is warped through the warmth of the sun the brackets will not fit easy and it's best to enlarge the holes of the brackets with a drill.



### STEP 11

Tighten all bolts. Don't tighten the bolts in the center with too much force since these are thin and can break if you use too much force.



## PREMIUM AFTERMARKET ROADSTER BARS & WIND DEFLECTORS

### STEP 12

Take the side cover and measure how you need to cut out. Take a small and cut out the shape.



### Step 13

Put the side cover back and use the plugs to hold the cover.



### STEP 14

Reattach the bottom cover





## PREMIUM AFTERMARKET ROADSTER BARS & WIND DEFLECTORS

### STEP 15

Attach the additional wind deflector using the supplied bolts. Install the plastic cap to cover the bolt.



### PLEASE NOTE

These bars have been TÜV approved they have not been crash tested and are not a safety device.

TÜV SÜD Automotive GmbH  
Gottlieb-Daimler-Straße 7  
D-70794 Filderstadt



Automotive

Nr.: 003  
Hersteller: Cabrio Supply  
Typ: Roadster Bügel

Seite 1 von 1

### Gutachterliche Stellungnahme

**Betreff:** Roadster Bügel (Cabrio)

**Antragsteller:** Cabrio Supply  
Radeweg 25  
NL - 8171MD Vaassen  
Niederland

Aufgabe:

Die Anbringung eines Roadster Bügel mittels Bolzen hinter dem Sitzen von Kraftfahrzeugen ist zu beurteilen.

Beispiel:



Beurteilung:

Diese Fahrzeugteile sind einem Dachgepäckträger gleichzusetzen.

Gemäß Beispielkatalog zum §19 StVZO erlischt die Betriebserlaubnis eines Fahrzeug nicht durch die Anbringung eines Dachträgers (siehe Punkt 6.12 des Beispielkatalogs) weil keine Genehmigung und / oder Teilegutachten erforderlich ist.

Dies gilt für Dachgepäckträger die die Vorschriften des § 30c StVZO erfüllen.

AM-HZBW; Filderstadt, den 26. 05. 2009,



Dipl.- Ing.(FH) Schwarz

Akkreditiert unter DAR-Registriernummer KBA-P-000001-95  
von der Akkreditierungsstelle des Kraftfahr-Bundesamtes, Bundesrepublik Deutschland